Operation/Reference Guide

Mio Modero®

Device Family

Control System Accessories

Last Revised: 12/16/2009

AMX Limited Warranty and Disclaimer

AMX warrants its products to be free of defects in material and workmanship under normal use for three (3) years from the date of purchase from AMX, with the following exceptions:

- Electroluminescent and LCD Control Panels are warranted for three (3) years, except for the display and touch overlay components that are warranted for a period of one (1) year.
- Disk drive mechanisms, pan/tilt heads, power supplies, and MX Series products are warranted for a period of one (1) year.
- AMX Lighting products are guaranteed to switch on and off any load that is properly connected to our lighting products, as long as the AMX Lighting products are under warranty. AMX does guarantee the control of dimmable loads that are properly connected to our lighting products. The dimming performance or quality cannot be guaranteed due to the random combinations of dimmers, lamps and ballasts or transformers.
- Unless otherwise specified, OEM and custom products are warranted for a period of one (1) year.
- AMX Software is warranted for a period of ninety (90) days.
- Batteries and incandescent lamps are not covered under the warranty.

This warranty extends only to products purchased directly from AMX or an Authorized AMX Dealer.

All products returned to AMX require a Return Material Authorization (RMA) number. The RMA number is obtained from the AMX RMA Department. The RMA number must be clearly marked on the outside of each box. The RMA is valid for a 30-day period. After the 30-day period the RMA will be cancelled. Any shipments received not consistent with the RMA, or after the RMA is cancelled, will be refused. AMX is not responsible for products returned without a valid RMA number.

AMX is not liable for any damages caused by its products or for the failure of its products to perform. This includes any lost profits, lost savings, incidental damages, or consequential damages. AMX is not liable for any claim made by a third party or by an AMX Dealer for a third party.

This limitation of liability applies whether damages are sought, or a claim is made, under this warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation of liability cannot be waived or amended by any person. This limitation of liability will be effective even if AMX or an authorized representative of AMX has been advised of the possibility of any such damages. This limitation of liability, however, will not apply to claims for personal injury.

Some states do not allow a limitation of how long an implied warranty last. Some states do not allow the limitation or exclusion of incidental or consequential damages for consumer products. In such states, the limitation or exclusion of the Limited Warranty may not apply. This Limited Warranty gives the owner specific legal rights. The owner may also have other rights that vary from state to state. The owner is advised to consult applicable state laws for full determination of rights.

EXCEPT AS EXPRESSLY SET FORTH IN THIS WARRANTY, AMX MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. AMX EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS LIMITED WARRANTY.

Table of Contents

Overview 1
Specifications 1
Available Color Schemes 2
Mio Modero LCD Feature 3
Fixed Menu System 3
Proximity Detection "People Sensor" 3
Installation 5
Changing Buttons 6
Switching Out "Installation" Buttons 6
Changing Custom Buttons 6
Mio Modero Prestige 7
Setting The AxLink Device Number 7
Wiring 8
Preparing captive wires 8
Wiring Guidelines 8
Connecting the Wiring 8
AxLink Data and Power Connections 9
Using AxLink For Data With an Auxiliary Power Supply 9
Mounting Procedures 10
Wallbox Mounting 10
Podium Mounting 11
Accent Frame 12
Mio Modero IR 13
Wiring and Installation 14
Setting the AxLink Device Number 14
Wiring Guidelines 14
AxLink Data and Power Connections 15
Checking AxLink Status 15
Mounting Procedure 15
Programming The Mio Modero 17
KeypadBuilder 17
SEND_COMMANDs 17
@BRT 17
^CFG 18
@CST 18
^FML S 18
^FML D 18
^FML D L 19
^FML D L # 19

^GLY 19
^JST- 19
^PRX- 20
^SHO 20
SLEEP 20
@SSL 20
@SST 20
@SWK 21
^TXT- 21
^UNI- 21
WAKE 21
Combining Buttons 22
Sending Firmware to The Mio Modero Keypads 22

Overview

The Mio Modero device family provides a wide range of control capabilities in the form of keypads that are as adept as they are elegant. Each device is available as single style (8 button max) or double style (16 button max) with an optional LCD capped button (FIG. 1).

FIG. 1 White, Single Style Classic; Black, Single Style Prestige; Gray, Double Style Elite with LCD

The devices are available as follows:

Mio Modero Device Family	
Classic	Engraved plastic buttons with a red (active) feedback LED in the upper left corner.
Prestige	Clear plastic capped buttons with laser printed inserts; a red (active) feedback LED in the upper left corner.
Elite	Painted and engraved plastic buttons, backlit with a blue (inactive) and red (active) feedback; available with an LCD button.
Mio Modero IR	IR receiver capable of accepting both 38kHz and 455kHz frequency bands.

Specifications

The Mio Modero device family keypad specifications are as follows:

Specifications			
Power:	12 vDC, 70 - 230 mA (range depending on device type and number of buttons)		
Front Panel Components:	• LCD (where applicable) - SPI controlled 96 x 96 pixel resolution, monochrome FSTN display with a white Electroluminescent backlight; an active button. • Pushbuttons - a maximum of 8 buttons on the single style and 16 buttons on the double style. The Classic and Prestige provide a direct LED light. • LEDs - red and blue backlit buttons indicate activity. Only present in the Elite devices.		
Rear Panel Components:	• DIP switch - 8 position mini DIP switch used to set the device address for the keypad on the AxLink Bus. • Wiring connection - 4 pin 3.5mm Phoenix AxLink connector.		
Dimensions (HWD):	• Single style - 4.46" x 2.71" x .57" (113.28 mm x 68.83 mm x 14.48 mm) • Double style - 4.46" x 4.39" x .57" (113.28 mm x 111.51 mm x 14.48 mm)		
Supported Languages:	• English • Spanish • French • Italian • German	• Portuguese • Arabic • Mandarin Chinese • Russian • Japanese	• Thai • Hindi • Korean • Hebrew • Greek

Specifications (Cont.)	
Weight (range):	.25 lbs (.11 kg) - .50 lbs (.23 kg)
Operating Environment:	• Operating Temperature: 0° to 50° C (32° to 122° F) • Storage Temperature: -10° to 70° C (14° to 158° F)
Mounting:	Mounts into US and a majority of International single gang back boxes.
Included Accessories:	• Single style mounting kit (KA-5795-01) • Double style mounting kit (KA-5795-02) • Mylar kit (Prestige only) - Sheets of common menu items and icons for creating inserts for single and double buttons. Available in either black, white, or beige. (66-5798-01WH, White; 66-5798-01BG, Beige; 66-5798-01BL, Black) • Phoenix Connector (41-5045) • Installation Buttons (Elite and Classic only)
Optional Accessories:	• **Accent Frame (for some larger wallboxes):** *Classic and Prestige Colors* (xx indicates color selection) - FG5795-08xx (single button); FG5795-09xx (double button) *Elite Colors* (xx indicates color selection) - FG5796-08xx (single button); FG5796-09xx (double button) • **Custom buttons:** *Classic Colors* (xx indicats color selection) - FG5795-21xx (4 single buttons); FG5795-22xx (2 double buttons) *Prestige Colors* (xx indicats color selection) - FG5798-05xx (4 single buttons); FG5798-06xx (2 double buttons) *Elite Colors* (xx indicats color selection) - FG5796-21xx (4 single buttons); FG5796-22xx (2 double buttons) • **Blank buttons:** *Classic Colors* (xx indicats color selection) - FG5795-07xx *Elite Colors* (xx indicats color selection) - FG5796-07xx

Available Color Schemes

The Mio Modero device family is available in a range of colors, and the Elite supports a variety of Lutron color schemes.

Mio Modero Color Schemes	
Mio Modero Classic	Black (BL), White (WH), Beige (BG)
Mio Modero Prestige	Black (BL), White (WH), Beige (BG)
Mio Modero Elite	Black (BL), White (WH), Beige (BG), Almond (AL), Brown (BR), Gray (GR), Ivory (IV), Light Almond (LA), Taupe (TP), Gold (GL), Silver (SL)
IR Receiver	Black (BL), White (WH), Beige (BG)
International Wall Plates	Black (BL), White (WH), Beige (BG), Almond (AL), Brown (BR), Gray (GR), Ivory (IV), Light Almond (LA), Taupe (TP), Gold (GL), Silver (SL)

Mio Modero LCD Feature

The Mio Modero Elite is available with an optional LCD screen. The LCD is a scalable black-and-white image (SPI) controlled 96 x 96 resolution monochrome FSTN display with a white Electroluminescent back light. The viewable area of the screen is 25 mm x 25 mm.

The LCD displays an 18 pt. font and supports 4 lines of text.

The viewing angle of the LCD is 12 o'clock, allowing for a top down viewing once mounted to a wall.

The LCD is capable of displaying levels via a bar graph and text over the bar graphs.

Additionally, the LCD has a button cap enabling it to act as a button.

Fixed Menu System

Using the KeypadBuilder application available for download from **www.amx.com**, the LCD can be programmed with a Fixed Menu System (FMS) that is navigated via the Mio Modero and its LCD button. See the *KeypadBuilder Instruction Manual* for more information on programming Fixed Menu Systems.

Proximity Detection "People Sensor"

The Mio Modero Elite has an electromagnetic field proximity detector or "People Sensor."

A disruption of the field within 4 to 6 inches will activate the keypad's backlight.

Installation

NOTE

Before touching the device, discharge the static electricity from your body by touching a grounded metal object.

The basic front and rear components of the Mio Modero are as follows:



FIG. 2 Mio Modero Front and Rear Components



FIG. 3 Sections of The Mio Modero

Changing Buttons

The Mio Modero Classic and Elite are shipped with "installation" buttons; they are intended to be place holders until your engraved buttons, designed with KeypadBuilder, arrive.

Switching Out "Installation" Buttons

1. Pry the button using the slot on the front of the "installation" buttons to remove them from the Mio Modero.
2. Select the location of the custom buttons and snap them into place.
   Be sure to note the orientation of the white insert on the back of the button, the notch must be down. Insert the bottom of the button first and then push the top into place.
3. Snap the faceplate on the mounting frame.

Changing Custom Buttons

1. If connected, disconnect the power supply.
2. If connected to mounting frame, place a flathead screwdriver in the notch at the bottom right of the Mio Modero, and pry the faceplate from the mounting frame.
3. On the back of the faceplate locate the button access points, outlined with white circles. Using a straightened paperclip, poke through the button access points until the buttons pop free.
4. Snap the desired custom buttons into place.
   Be sure to note the orientation of the white insert on the back of the button, the notch must be down. Insert the bottom of the button first and then push the top into place.
5. If the power supply was disconnected in **Step 1**, reconnect and return power to the device.
6. Snap the faceplate on the mounting frame.

Be certain to reprogram the Mio Modero to match the new button arrangement; use KeypadBuilder to assign the locations. See the *KeypadBuilder Instruction Manual* available at **www.amx.com**.

Mio Modero Prestige

The Mio Modero Prestige ships with sheets of common menu items and icons for creating inserts for single and double buttons.

1. If connected, disconnect the power supply.
2. If connected to mounting frame, place a flathead screwdriver in the notch at the bottom right of the Mio Modero, and pry the faceplate from the mounting frame.
3. On the back of the faceplate locate the button access points, outlined with white circles. Using a straightened paperclip, poke through the button access points until the buttons pop free.
4. The Prestige buttons are comprised of three parts, the frame, window, and back insert. From the front of the button, use your thumb to poke the window and back insert out of the frame. See FIG. 4.



FIG. 4 Prestige Button Components

5. Snap the widow into the frame and then place the printed labels inside each button.
6. Snap the back inset to the window and frame.
7. Insert the buttons into their proper location on the faceplate.
8. If the power supply was disconnected in **Step 1**, reconnect and return power to the device.
9. Snap the faceplate on the mounting frame.

Setting The AxLink Device Number

1. If connected, disconnect the power supply.
2. Locate the 8-position Device DIP switch on the rear panel.(FIG. 5).
3. Set the DIP switch according to the switch values shown below.

Switch	1	2	3	4	5	6	7	8
Value	1	2	4	8	16	32	64	128

The device number is set by the total value of DIP switch positions that are ON (up).

As an example, the DIP switch in FIG. 5 defines device number 129 (1+128=129).

FIG. 5 Example Device DIP Switch set to 129

If you later change the device number, remove and reconnect the AxLink power connector to enter the new device number into memory.

NOTE

*AMX has created Dip Switch2 to assist in calculating dip switch position values. Download the program Dip Switch2 from **www.amx.com** for free.*

Wiring

The Mio Modero uses a four-pin mini AxLink connector for power and data.

CAUTION

Do not connect power to the Mio Modero until the wiring is complete.

Preparing captive wires

You will need a wire stripper, and flat-blade screwdriver to prepare and connect the captive wires.

1. Strip 0.25 inch (6.35 mm) of wire insulation off all wires.
2. Insert each wire into the appropriate opening on the connector according to the wiring diagrams and connector types described in this section.
3. Turn the flat-head screws clockwise to secure the wires in the connector.

NOTE

Do not over-torque the screws; doing so can bend the seating pins and damage the connector.

Wiring Guidelines

The Mio Modero requires 12 VDC power to operate properly. The necessary power is supplied via the AxLink cable. The maximum AxLink wiring distance is determined by power consumption, supplied voltage, and the wire gauge used for the cable.

The following table lists wire sizes and the maximum lengths allowable based on the maximum power consumption rating of 170 mA.

Wiring Guidelines at 170 mA	
Wire Size	**Maximum Wiring Length**
18 AWG	690.42 feet (210.43 m)
20 AWG	436.80 feet (133.13 m)
22 AWG	272.33 feet (83.00 m)
24 AWG	171.66 feet (52.32 m)

The maximum wiring lengths for using AxLink power are based on a minimum of 13.5 volts available.

Connecting the Wiring

The following paragraphs describe wiring connections for using the AxLink and relay connectors.

CAUTION

If using power from AxLink, disconnect the wiring from the control system before wiring the Mio Modero.

AxLink Data and Power Connections

Connect the control system's AxLink connector to the AxLink connector on the rear panel of the Mio Modero for data and 12 VDC power as shown in FIG. 6.



FIG. 6 AxLink straight-thru wiring

Using AxLink For Data With an Auxiliary Power Supply

Connect the controller's AxLink connector to the AxLink connector on the rear panel of the Mio Modero device, as shown in FIG. 7.



FIG. 7 AxLink and 12 VDC power supply wiring diagram

CAUTION

If you are not using power from AxLink, disconnect the wiring from the controller before wiring the Mio Modero device. Make sure the auxiliary power supply's PWR (+) is not connected to the controller's AxLink connector.

Use an auxiliary 12 VDC power supply when the distance between the controller and server exceeds the limits described in Wiring Guidelines table.

Connect only the GND (-) wire on the AxLink connector when using an auxiliary 12 VDC power supply.

Mounting Procedures

FIG. 8 shows the wallbox mounting dimensions for the single and double style Mio Modero. AMX recommends mounting the Mio Modero in a standard one-gang wallbox, a conduit box per NEC specs section 370, with a minimum internal clearance of 2-5/8" x 1-3/4" x 1-5/8" (HWD), but it is possible to mount the Mio Modero to a podium without a wallbox.



FIG. 8 Mio Modero Single Style mounting dimensions



FIG. 9 Mio Modero Double Style mounting dimensions

Wallbox Mounting

1. Use the cutout dimension for the wallbox to cutout the install surface for the Mio Modero.
2. Confirm that the terminal end of the AxLink cable is disconnected, and not receiving power.
3. If the faceplate is connected to the mounting frame, place a flathead screwdriver in the notch at the bottom right of the Mio Modero, and pry the faceplate from the mounting frame.
4. Connect the AxLink power supply. The connector passes through the center of the mounting frame and connects to the board. The connection is illustrated in FIG. 2.
5. Place the mounting frame on the wallbox; align the screw holes with the mounting holes and fasten the mounting frame to the wallbox using the screws supplied.

NOTE

Do not overtighten the screws when mounting the mounting frame. The device should be flush with mounting surface.

6. Attach the faceplate to the mounting frame first at the top and swing it to the bottom. See FIG. 10.



FIG. 10 Attaching the faceplate to the mounting frame

Podium Mounting

1. Use the cutout dimension shown in either FIG. 8 or FIG. 9 to cutout the mounting frame install surface for the Mio Modero.
2. Confirm that the terminal end of the AxLink cable is disconnected, and not receiving power.
3. If the faceplate is connected to the mounting frame, place a flathead screwdriver in the notch at the bottom right of the Mio Modero, and pry the faceplate from the mounting frame.
4. Connect the AxLink power supply. The connector passes through the center of the mounting frame and connects to the board. The connection is illustrated in FIG. 2.
5. With the mounting frame resting in the cutout area, drill the mounting holes into the flat surface.

NOTE

Do not overtighten the screws when mounting the mounting frame. The device should be flush with mounting surface.

6. Attach the faceplate to the mounting frame first at the top and swing it to the bottom (see FIG. 10).

Accent Frame

While the Mio Modero device family does fit into many International wallboxes, it may be necessary to utilize the optional accent frame to completely cover the wallbox.

To install the Mio Modero with the optional accent frame:

1. Use the cutout dimension for the wallbox to cut out the install surface for the Mio Modero.
2. Place the accent frame on the wallbox; align the screw holes with the mounting holes on the wallplate. Fasten the wallplate to the wallbox.

   Based on the extensive number of international wallboxes it is not pragmatic to ship every possible screw that could be used. Please use the screws appropriate for your specific wallbox.

Do not overtighten the screws when mounting the mounting frame. The device should be flush with mounting surface.

3. Confirm that the terminal end of the AxLink cable is disconnected, and not receiving power.
4. If the faceplate is connected to the mounting frame place a flathead screwdriver in the notch at the bottom right of the Mio Modero IR, and pry the faceplate from the mounting frame.
5. Connect the AxLink power supply. The connector passes through the center of the mounting frame and connects to the board. The connection is illustrated in FIG. 2.
6. Place the mounting frame on the accent frame; align the screw holes with the mounting holes and fasten the mounting frame to the wallplate. The Accent Frame is shipped with two #6-32 x .187 long flat head screws (80-131); these are used to attach the Mio panel to the accent frames.
7. Snap the faceplate to the mounting frame.

Mio Modero IR

The Mio Modero IR (FIG. 11) is a remote IR receiver for use with NetLinx® Central Controllers and operates via the AxLink bus to remotely control devices.

- The Mio Modero IR is in a wall panel that fits into the US-style single-gang enclosure and most International single-gang enclosures.
- The Mio Modero IR works with AMX 38 kHz and 455 kHz IR transmitters.



FIG. 11 Mio Modero IR receiver

Mio Modero IR Specifications	
Power:	12 vDC, 15 mA
Receive Frequencies:	38 and 455 kHz
Range:	**38KHz:** • Transmitter at 38Hz = max of 95 feet line of sight • Transmitter at 38Hz and at 50° horizontal angle from center = 55 feet • Transmitter at 38Hz and at 30° vertical angle from center = 65 feet **455KHz:** • Transmitter at 455Hz = max of 58 feet line of sight • Transmitter at 455Hz and at 45° horizontal angle from center = 31 feet • Transmitter at 455Hz and at 45° vertical angle from center = 35 feet
Mounting:	Mounts into US-style single-gang enclosures and most International single-gang enclosures.
Dimensions (HWD):	4.46" x 2.71" x .57" (113.28 mm x 68.83 mm x 14.48 mm)
Weight:	.15 lbs (.07 kg)

Wiring and Installation

Set the receive AxLink device number before installing the Mio Modero IR. FIG. 12 illustrates the location of key components on the Mio Modero IR circuit board.



FIG. 12 Location of key components on the Mio Modero IR circuit board

Setting the AxLink Device Number

1. If connected, disconnect the power supply.
2. Locate the 8-position Device DIP switch (FIG. 12).
3. Set the DIP switch according to the DIP switch values shown below.

Switch	1	2	3	4	5	6	7	8
Value	1	2	4	8	16	32	64	128

The device number is set by the total value of DIP switch positions that are ON (up).

As an example, the DIP switch in FIG. 13 defines device number 129 (1+128=129).

FIG. 13 Example Device DIP Switch set to 129

If you later change the device number, remove and reconnect the AxLink power connector to enter the new device number into memory.

Wiring Guidelines

The Mio Modero IR requires 12 VDC power to operate properly. The power is supplied by the AMX system's AxLink cable. The maximum wiring distance between the Central Controller and the receiver is determined by power consumption, supplied voltage, and the wire gauge used for the cable.

The following table lists wire sizes and the maximum lengths allowable between the receiver and the Central Controller. The maximum wiring lengths are based on a minimum of 13.5 volts available at the Central Controller's power supply.

Wiring Specifications @ 35 mA	
Maximum Wiring Length	
Wire Size	Distance
18 AWG	3000 feet (914.40 m)
20 AWG	2121.64 feet (646.68 m)
22 AWG	1,322.75 feet (403.17 m)
24 AWG	833.80 feet (254.14 m)

AxLink Data and Power Connections

The Mio Modero IR uses a four-pin mini AxLink connector for power and data.

Connect the control system's AxLink connector to the AxLink connector on the rear panel of the Mio Modero IR for data and 12 VDC power as shown in FIG. 14.



FIG. 14 AxLink straight-thru wiring

For wire prepartaion guidelines, refer to *Preparing captive wires* section on page 8.

Checking AxLink Status

The AxLink LED, shown in FIG. 12, lights to indicate AxLink power/data status as follows:

- **1 blink per second** Indicates power is active and AxLink communication is working.
- **2 blinks per second** Indicates the devices specified in the Master program do not match the devices found.
- **3 blinks per second** Indicates AxLink communication error.
- **Full On** Indicates the following conditions:
  - There is no AxLink control or activity, but power is On.
  - The Axcess program is not loaded.

If the LED is on and not flashing, disconnect the AxLink connector and recheck all AxLink connections. Then, reconnect the AxLink connector to the panel and verify the LED is flashing once per second.

Mounting Procedure

FIG. 15 shows the wallbox mounting dimensions for the Mio Modero IR.

AMX recommends mounting the Mio Modero IR in a standard one-gang wallbox, a conduit box per NEC specs section 370, with a minimum internal clearance of 2-5/8" x 1-3/4" x 1-5/8" (HWD).



FIG. 15 Mio Modero IR mounting dimensions

1. Use the cutout dimension for the wallbox to cutout the install surface for the Mio Modero IR.
2. Confirm that the terminal end of the AxLink cable is disconnected, and not receiving power.
3. If the faceplate is connected to the mounting frame, place a flathead screwdriver in the notch at the bottom right of the Mio Modero IR, and pry the faceplate from the mounting frame.
4. Connect the AxLink power supply. The connector passes through the center of the mounting frame and connects to the board.
5. Place the mounting frame on the wallbox; align the screw holes with the mounting holes and fasten the mounting frame to the wallbox using the screws supplied.
6. Attach the faceplate to the mounting frame first at the top and swing it to the bottom. See FIG. 16.



FIG. 16 Attaching the faceplate to the mounting frame

Programming The Mio Modero

KeypadBuilder

Most functionality of the Mio Modero is handled using the application, *KeypadBuilder*. Go to **www.amx.com** for the *KeypadBuilder Instruction Manual*.

There are a select number of SEND_COMMANDs the Mio Modero recognizes.

SEND_COMMANDs

Below is a list of SEND_COMMANDs accepted by the Mio Modero device family from NetLinx masters. As indicated, not every command applies to all Mio Modero devices, e.g., the ^TXT command is not apparent without an LCD upon which to display.

All text is based on a Unicode index.

To use these commands, establish a Telnet session from the PC to the NetLinx master.

SEND_COMMANDs	

@BRT	Set Brightness level
	Syntax:
	`"'BRIT-<tag>,<awake brightness level>,<sleep brightness level>'"`
	Variables:
	• brightness level # = a value from 0 - 32.
	• tag = Red or Blue; affected LCDs
	"'@BRT-#'" (Set LED Awake brightness level)
	"'@BRT-##'" (Set LED Awake brightness level, sleep brightness level)
	"'@BRT-tag#'" (Set Red or Blue LED, brightness level)
	"'@BRT-tag##'" (Set Red or Blue LED, awake brightness level, and sleep brightness)
	Examples:
	`(1) SEND_COMMAND Panel,"'@BRT-16'"`
	Sets the awake brightness level to 50%.
	`(2) SEND_COMMAND Panel,"'@BRT-32,5'"`
	Sets the awake brightness level to 100% and sleep brightness level to approximately 15%
	`(3) SEND_COMMAND Panel,"'@BRT-RED,32'"`
	Sets the red LED awake brightness level to 100%.
	`(4) SEND_COMMAND Panel,"'@BRT-BLUE,32,5'"`
	Sets the Blue LED awake brightness level to 100% and sleep brightness level to Approximately 15%

SEND_COMMANDs (Cont.)	

^CFG	Set Keypad to Combine Mode. Combine mode allows yu to combine/uncombine adjacent buttons on the Keypad.
	Syntax:
	`"'^CFG- <command value>'"`
	Variables:
	• command value = (1= enter combine mode, 0= exit combine mode).
	Example:
	`SEND_COMMAND Panel,"'^CFG-1'"`
	Sets the Keypad to button combine mode.
	***Note**: While in button combine mode, no pushes will be sent.*
	Place the Keypad into button combine mode, and hold down two adjacent buttons for 2 seconds to combine them.
	• When two buttons have been pressed for 2 seconds, the LED on the left button will flash to indicate they are combined.
	• If you press two buttons that are already combined, they will be uncombined. The indication is that both button LEDs will flash alternately.
	See the *Combining Buttons* section on page 22 for details.

@CST	Sets the display contrast for the device.
	Syntax:
	`"'@CST-<Contrast Level>'"`
	Variables:
	• Contrast Level = a value from 0 - 31.
	Example:
	`SEND_COMMAND Panel,"'@CST-15'"`
	Sets the display contrast to approximately 50%.

^FML S	Sets a line of the display to a menu line
	Syntax:
	`"'^FML-<variable text address range>,S'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• S = Static line type
	Example:
	`SEND_COMMAND Panel,"'^FML-1,S'"`
	Sets dynamic line 1 to a menu line

^FML D	Sets a line of the display to a dynamic line with no level
	Syntax:
	`"'^FML-<variable text address range>,D'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• D = Dynamic line type
	Example:
	`SEND_COMMAND Panel,"'^FML-2,D'"`
	Set Line 2 to a Dynamic Line with no Level

SEND_COMMANDs (Cont.)	

^FML D L	Sets a line of the display to a dynamic line with a level
	Syntax:
	`"'^FML-<variable text address range>,D,L'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• D = Dynamic line type
	• L = Level
	Example:
	`SEND_COMMAND Panel,"'^FML-1,D,L'"`
	Set line 1 to a Dynamic line with level

^FML D L #	Sets a line of the display to a dynamic line with a level, and sets the level style
	Syntax:
	`"'^FML-<variable text address range>,D,L,<Level Style>'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• D = Dynamic line type
	• L = Level
	• level style = 0 or 1 for level style type
	Example:
	`SEND_COMMAND Panel,"'^FML-1,D,L,0'"`
	Set line 1 to a Dynamic line with level and set style to 'Level Style 0'

^GLY
(LCD equipped only)
	Set Glyph Character.
	Syntax:
	`"'^GLY-<variable text address range>,',<glyph number>"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• glyph number = glyph text.
	Example:
	`SEND_COMMAND Panel, "'^GLY-1&4,',2"`
	Sets the second glyph character on dynamic lines 1 and 4 of the LCD button.

^JST-
(LCD equipped only)
	Set text alignment using a numeric keypad layout for those buttons with a defined address range
	Syntax:
	`"'^JST-<variable text address range>,<new text alignment>'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• new text alignment = Value of 1 - 9 corresponds to the following locations:
	1, 4 or 7 = Left
	2, 5 or 8 = Center
	3, 6 or 9 = Right
	Example:
	`SEND_COMMAND Panel,"'^JST-1.4,1'"`
	Sets the text alignment to the left side on dynamic lines 1, 2, 3 and 4 of the LCD button
	Note: *There is no vertical alignment.*

SEND_COMMANDs (Cont.)	

^PRX-	Sets the sensitivity for the proximity sensor.
	Syntax:
	`"'^PRX-#'"`
	Variable:
	• # = a value from 0 - 31.
	Example:
	`SEND_COMMAND Panel,"'^PRX-15'"`
	Sets the proximity sensor for the device to a level of approximately 50%.

^SHO	Show or hide text with a set variable text range.
	Syntax:
	`"'^SHO-<variable text address range>,<command value>'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• command value = (0= hide, 1= show).
	Example:
	`SEND_COMMAND Panel,"'^SHO-1,0'"`
	Hides text on dynamic line 1 of the LCD button.

SLEEP	Force the device into screen saver mode.
	Syntax:
	`"'SLEEP'"`
	`"'SLEEP-#'" (timed sleep; a persistent command)`
	Variable:
	• # = 0 - 60 in seconds; time to wait before going to sleep. Default is 30. 0 sets the device to never sleep.
	Example:
	`SEND_COMMAND Panel,"'SLEEP-45'"`
	Forces the device into screen saver mode after 45 seconds.

@SSL	Sends a string to the master upon going to sleep.
	Syntax:
	`"'@SSL-<new text>'"`
	Variable:
	• new text = 1 - 20 ASCII characters. Default string is SLEEP.
	Example:
	`SEND_COMMAND Panel,"'@SSL-KeyPad Sleep'"`
	Sends the string " KeyPad Sleep' to the master at time of sleep.

@SST	Sends a string to the master upon start up.
	Syntax:
	`"'@SST-<new text>'"`
	Variable:
	• new text = 1 - 20 ASCII characters. Default string is STARTUP.
	Example:
	`SEND_COMMAND Panel,"'@SST-Panel Start'"`
	Sends the string " Panel Start " to the master at time of start up.

SEND_COMMANDs (Cont.)	

@SWK	Sends a string to the master upon wake up.
	Syntax:
	`"'@SWK-<new text>'"`
	Variable:
	• new text = 1 - 20 ASCII characters. Default string is WAKEUP.
	Example:
	`SEND_COMMAND Panel,"'@SWK-Wake KeyPad"`
	Sends the string " Wake KeyPad " to the master at time of wake up.

^TXT-
(LCD equipped only)
	Assign a text string to those LCD buttons with a defined address range. Sets non unicode text.
	Syntax:
	`"'^TXT-<variable text address range>,<new text>'"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• new text = 1 - 20 characters (uses one byte Unicode values for all text characters).
	Examples:
	`1. SEND_COMMAND Panel,"'^TXT-1&3,Test Only'"`
	Sets the text "Test Only" on dynamic lines 1 and 3 of the LCD button.
	`2. SEND_COMMAND Panel,"'^TXT-2.4,'"`
	Clear text on dynamic lines 1 through 4 of the LCD button.

^UNI-
(LCD equipped only)
	Set Unicode text. The Unicode text is sent as a two byte HEX value.
	Syntax:
	`"'^UNI-<variable text address range>,',<unicode text>"`
	Variables:
	• variable text address range = 1 - 4; the address range corresponds to the dynamic line number.
	• unicode text = Unicode HEX value.
	Example:
	`SEND_COMMAND Panel, "'^UNI-1&4,',$00,$BD,$00,$B5"`
	Sets the Unicode characters '½µ' on dynamic lines 1 and 4 of the LCD button.
	Note: *Unicode is always represented in a two byte HEX value.*

WAKE	Force the device out of screen saver mode.
	Syntax:
	`"'WAKE'"`
	Example:
	`SEND_COMMAND Panel,"'WAKE'"`
	Forces the device out of the screen saver mode.

Combining Buttons

Use the **^CFG** Send Command (see page 18) to combine/uncombine adjacent buttons on the Keypad:

NOTE

The variables for the ^CFG command value are: 1= enter combine mode, 0= exit combine mode.

1. Send the following Send Command to the Keypad, to set the Keypad to button combine mode:

```
SEND_COMMAND Panel,"'^CFG-1'"
```

NOTE

While in button combine mode, no pushes will be sent.

2. Hold down two adjacent buttons for 2 seconds.
3. When the two buttons have been pressed for 2 seconds, the LED on the left button will flash to indicate they are combined.

If you press two buttons that are already combined, they will be uncombined. The indication is that both button LEDs will flash alternately.

Combine mode can be exited by sending the command '^CFG-0' or by disconnecting the keypad from power to reboot it.

Sending Firmware to The Mio Modero Keypads

NOTE

You will need the NetLinx Studio software application (available to download from www.amx.com) to update firmware located on the Mio Modero Keypads.

To send firmware to the keypads:

1. Open NetLinx Studio.
2. Go to **Tools > Firmware Transfers > Send to Axcess Device...** This opens the *Send to Axcess Dialog*. Browse to the location of the firmware file.
3. Select the file within the *Files* frame.
4. Click **Query for Devices**.
5. Select the Mio Modero Keypad within the *Devices* frame.
6. Click **Send** and then **Close**.
7. Upon confirmation of a successful send, you can exit NetLinx Studio.

It's Your World - Take Control™

3000 RESEARCH DRIVE, RICHARDSON, TX 75082 USA • 800.222.0193 • 469.624.8000 • 469-624-7153 fax • 800.932.6993 technical support • www.amx.com

12/09 ©2009 AMX. All rights reserved. AMX and the AMX logo are registered trademarks of AMX. AMX reserves the right to alter specifications without notice at any time.